



Description and usage

Inclines and Declines are the way you get product from one level to another, it could be from the floor to a mezzanine, or from the floor to overhead conveyor, anywhere a "height" change is needed this is the way to do it.

Inclines and Declines come in various widths, and of course lengths, several different belt designs are used depending on the product you want to convey. Be careful when planning the use of inclines or declines, because the angle there used at is of the utmost importance!